



FW download link: [Firmware](#) download  
Support NVR series: NVR5xxx-4KS2

Hereinbelow is the setting I made. Just for the function test, hope it can make you understand easily.



**#Step2:** Enable the Mobile Push Notification in advance, and select the "off" as disarming status, so once you trigger the alarm input 1, the disarming status will change to "On", then the NVR will stop send the push notification to DMSS app.



**#Step3:** Alarm input 1 connection. (P.s. You need to keep the alarm input status to keep the disarming status "on", it kinds like using a switch button, not click button.)

